



M32 Studio Marimba



E50250050


E50250050 Frame with hardware
Comes with posts and insulators & leg straps.
Also includes:

- E4061** Resonator plate (4)
- E4065** Resonator rubber (4)
- E3809** HE Resonator mount (2)
- E39451** Handle, painted.



E3844

E3844 Resonator assy, plain.



E3845

E3845 Resonator assy, sharp.



E0905

E0905 End post (8 per instrument)



E0910

E0910 Piper hook post (108 per instrument)



E1902V

E1902V Cord spring (2pk)
Order 2 packs for one instrument.




E0301

E0301 Post insulator (108 per instrument)
E0301 insulator for E0910 posts.

E0305T Insulator (10pk) 10 per inst.
E0305T insulator for E0905 posts and leg stops.



E4441V Green bar cord (2pk)



E49301FUL

E49301FUL Set of bars for M32, A=442
E49301FULW0 Set of bars for M32, A=440
 Standard tuning changed from A=440 to A=442 on 1/1/94
E49301xxx Individual bars for M32
 (Ex: Middle C is E49301CN4, 1/2 step up is E49301CS4)

M32 parts, cont.



E6161



E9784




E6160

- E6161** Knob w/stud 5/16-18
- E9784** Thru hole knob 5/16-18
- E6160** Leg extension

- E38611** HE Leg assy (includes E2590)
- E38601** LE Leg assy (includes E2590)

To convert to adj ht legs, order:

qty	Part #	description
1	E38615	HE leg assy
1	E38605	LE leg assy
4	E6160	Leg extension
2	E0140	Caster, plain
2	E0141	Caster, brake
4	E6161	Knob w/ stud
4	E9784	Thru hole knob
2	E9520	Velcro strap 16"




- E4074** HE leg brace
- E4069** LE leg brace
- E4491** Add on Carrier Bracket (on frame)
- E2590** Wing Nut
- E2460** 1/4-20 lock nut

E2590 connects brace to leg assy
E2460 connects brace to Carrier Bracket



E2590



E0140


- expandable stem casters
- E0140** plain caster for adj ht inst
- E0141** brake caster for adj ht inst
- E0135** plain caster for fixed ht inst
- E0136** brake caster for fixed ht inst

M44 Combo Vibraphone



E4600

E4600 Motor assembly
E4598 On/Off switch
E4597 Switch plate




E4598




E0407

E0407 Vibe motor belt
5 3/4" dia. (18.06" long)



E4540

E4540 Resonator and pulsator assembly, plain




E4885

E4885 Lower crossbar assembly

E4882 Low end brace (A)

E4883 High end brace (B)

Tops of diagonal braces connect to E4491 bracket
with E2590 wing nut



E4541

E4541 Resonator and pulsator assembly, sharp

E4573 Pulsator shaft assembly, plain

E4574 Pulsator shaft assembly, sharp

E4577 LE/HE Bearing bracket

E4578 Center bearing bracket

E3157 Nyliners



E51140030

E51140030 M44 Frame w/hardware

E4579 LE Resonator rubber

E4580 LE Resonator plate


E4113 Damper Spring Bracket

E39451 Handle

E4491 Add on carrier bracket

E2590 Wing nut


M44 parts, cont.



E38605 LE adj ht leg assy


E38615 HE adj ht leg assy

order leg extensions and casters separately



E4557

E4557 Damper bar assembly



E3358

E3358 Damper felt 1/2" X 1 1/2" X 37 5/8"



E6160

E6160 Leg extension



E0140

E0140 Exp stem caster, plain (adj ht)

E0141 Exp stem caster, brake (adj ht)

E0135 Exp stem caster, plain (fixed ht)

E0136 Exp stem caster, brake (fixed ht)



E4582

E4582 High end damper arm



E4583

E4583 Low end damper arm

E3272 Mounting clip for E4583



E9784

E4584 Mounting clip for E4584

E9784 5/16-18 Thru-knob

E6161 5/16-18 Plastic k




E6161



E3206

E3206 Felt washer



E32031

E32031 Damper adjustment nut

E2477 Wing nut for damper spring

To convert to adj ht legs, order:

qty	Part #	description
1	E38615	HE leg assy
1	E38605	LE leg assy
4	E6160	Leg extension
2	E0140	Caster, plain
2	E0141	Caster, brake
4	E6161	Knob w/ stud
4	E9784	Thru hole knob
1	E9520	Velcro strap 16"




E45881

E45881 Damper Spring



E2477

M44 parts, cont.



E4566FUL Full set of bars for M44 tuned to A=442

E4566FULW0 Full set of bars for M44 tuned to A=440

Standard tuning changed from A=440 to A=442 on 1/1/94

E4566xxx Individual bars for M44

(Ex: Middle C = E4566CN4, 1/2 step up is E4456CS4)



E0900T

E0900T Saddle post (10 pk)
40 per instrument



E0901T

E0901T Hook post (10pk)
40 per instrument



E0903T

E0903 Closed hole post (10 pk)
80 per instrument (old style)



E0300T

E0300T Post insulator (10 pk)
88 per instrument



E1902V

E1902V Cord Spring (2 pk)
Order 2 packs for one instrument



E1904V

E1904V Cord Spring, old style (2 pk)
Order one pack for one instrument

E4441V Bar cord

Order 1 pack for one instrument




E0905

E0905 Corner Post
4 per instrument
Used on rails 1 & 4



E0912


E0912 End post
4 per instrument
Used on rails 2 & 3



E32261

E32261 Lower pullrod only
E9487 Adjustment knob

E9487




E94965

E94965 Pedal assy w/lower plrd (after 6/1/00)

E94963 Pedal assy w/lower plrd (before 6/1/00)


E9784 Thru knob to secure to crossbar (after 6/1/00)



E3474

E3474 Upper pull rod

M46 One Nighter Vibraphone



E64921

E64921 Resonator and pulsator assembly, plain
E64931 Resonator and pulsator assembly, sharp




E64931




E0406

E0406 M46 belt



E33281

E33281 Pulsator shaft pulley




E3497

E3497 Belt Cover plate



E50380040

E50350040 M55 Frame w/hardware- no motor
 (comes with damper bar installed)



E3486

E3486 Lower crossbar with diagonal braces.


- A** **E34801** Low end leg brace
- B** **E94567** Low end crossbar brace
- C** **E94568** High end crossbar brace
- D** **E34811** High end leg brace
- E4491** Add on carrier bracket
- E2590** 1/4-20 wing nut

Tops of diagonal braces connect to E4491 bracket
 This crossbar will work on models made after 1980,
 and earlier models with some modifications.

M46 parts, cont.



E38605 LE adj ht leg assy
E38615 HE adj ht leg assy




E38615

order leg extensions and casters separately



E6160



E0140

- E6160** Leg extension
- E0140** Exp stem caster, plain (adj ht)
- E0141** Exp stem caster, brake (adj ht)
- E0135** Exp stem caster, plain (fixed ht)
- E0136** Exp stem caster, brake (fixed ht)



E6161

E6161 5/16-18 Plastic knob



E9784

E9784 5/16-18 Thru-knob


To convert to adj ht legs, order:

qty	Part #	description
1	E38615	HE leg assy
1	E38605	LE leg assy
4	E6160	Leg extension
2	E0140	Caster, plain
2	E0141	Caster, brake
4	E6161	Knob w/ stud
4	E9784	Thru hole knob
2	E9520	Velcro strap 16"




E0900T

E0900T Saddle post (10 pk)
 40 per instrument



E0901T

E0901T Hook Post (10 pk)
 40 per instrument



E0905

E0905 End post
 4 per instrument
 Used on rails 1 & 4



E0300T

E0300T Post insulator (10 pk)
 88 per instrument



E0912

E0912 End post
 4 per instrument
 Used on rails 2 & 3

M46 parts, cont




E3476



E3477

- E3476** Low end damper arm
- E3272** Mounting clip for E3476
- E3477** High end damper arm
- E3217** Mounting clip for E3477



E3200

- E3200** Damper bar assembly
- E3215** Eye hook 1/4 20 x 2"
- E2455** Hex nut 1/4 20 (2 req to hold eye hook)
- E3202** Damper stud




E94963




E3734

- E94965** Pedal assy w/lower plrd (after 1/2/01)
- E94963** Pedal assy w/lower plrd (before 1/2/01)
- E9784** Thru knob to secure to crossbar (after 1/2/01)
- E3734** Upper pull rod




E3279

E3279 Damper felt 1/2" X 1 1/2" X 51"



E32261

- E32261** Lower pullrod only
- E9487** Adjustment knob



E37764FUL

- E37764FUL** Full set of bars for M46 tuned to A=442
 - E37764xxx** Individual bars for M46
- (Ex: Middle C = E37764CN4, 1/2 step up is E37764CS4)



E32111

- E32111** Damper Spring
- E3952** Damper spring bracket



E9487




E1902V

- E1902V** Cord Spring (2 pk)
- Order 2 packs for one instrument
- E4441V** Bar cord
- Order 1 pack for one instrument



E2477

E2477 Wing nut for damper spring




E32031

- E32031** Damper adjustment nut
- E3206** Felt washer




E3206

M48 Pro Traveler Vibraphone



E3646

- E3646 Motor and control assy
- E36191 Motor w/connector
- E3634 Motor control unit
- E3617 ON/OFF switch
- E3632 Small potentiometer
- E3621 Control box mounting bracket
- E3630 Speed control knob
- E30601 Motor Panel w/Pins



E3630



E9436

- E9436 Plain resonator and pulsator assembly
- E9438 Plain pulsator shaft assembly





E9437

- E9437 Sharp resonator and pulsator assembly
- E9439 Sharp pulsator shaft assembly
- E3154 LE bearing bracket
- E3156 Center bearing brkt
- E3155 HE bearing bracket
- E3157 Nyliners
- E9487 1/4-20 plastic male knob



E9487

E9487 fastens resonator sections as shown below.



E3497

- E3497 Belt cover plate



E3631

- E3631 Motor Pulley




E0412

- E0412 Motor mounting ring



E0408

- E0408 Belt




E33281

- E33281 Resonator pulley

- E9457 #1 Rail assembly (closest to player)
- E9459 #2 Rail assembly
- E4491 Add on carrier bracket (for diag. braces)
- E9461 #3 Rail assembly
- E9463 #4 Rail assembly (farthest from player)
- E3017 Hinge assembly (same on all 4 rails)

M48 parts, cont



E9490


E9490 Crossbar assembly

- A** **E9494** Low end leg brace
- B** **E94862** Low end crossbar brace
- C** **E94565** High end crossbar brace
- D** **E9493** High end leg brace
- P1354** Plastic T handle knob
- E4491** Add-on carrier bracket
- E2590** Wing nut (braces to frame)




E0900T

E0900T Saddle post (10 pk)
40 per instrument




E0901T

E0901T Hook Post (10 pk)
40 per instrument



E0905

E0905 End post (rail 1&4)
4 per instrument




E0912

E0912 End Post (rail 2&3)
4 per instrument



P1534

P1534 T handle



E0117

E0117 Caster



E0300T


E0300T Post Insulator (10 pk)
88 per instrument

Parts of E9471 low end assembly

- E3456** Rail Bracket for #1
- E34411** Rail Bracket for #2
- E34401** Rail Bracket for #3
- E9472** Rail Bracket for #4
- E3216** LE damper bracket
- E3125** LE resonator plate, plain
- E3126** LE resonator plate, sharp
- E3127** LE resonator rubber (2)
- E3131** Fiber plate (2)
- E0302** Insulator (4)

Parts of E9474 HE assembly

- E3547** HE rail bracket for #1
- E9475** HE rail bracket for #4
- E0302** Insulator (2)



E9478 LE leg
E9471 LE assy

E9479 HE leg
E9474 HE assy

P1534 Plastic T-handle

P1534 connects leg assemblies to end pcs.




E1902V

E1902V Cord Spring (2 pk)
Order 2 packs for one instrument

E4441V Green bar cord (2 pk)


M48 parts, cont



E94961 Pedal and Pulrod assy
P1534 Female T handle (not shown)
 (P1534 connects the pedal to crossbar)
E9487 Male plastic knob
 (E9487 secures lower pullrod to upper)
E7323T Pedal felt (10 pk)



E34741
E34741 Upper pullrod



E3476 Low end damper arm
E3216 Mounting clip for E3476
E3477 High end damper arm
E3217 Mounting clip for E3477



E9487



E2477

E2477 Wing nut



E3206

E3206 Felt Washer



E32031

E32031 Damper adj nut




E32111

E32111 Damper spring




E3213

E3213 Damper spring bracket



E3279

E3279 Damper felt 1/2" X 1 1/2" X 51"



E37762FUL


E37762FUL Full set of bars for M48 tuned to A=442

E37762FULW0 Full set of bars for M48 tuned to A=440

Standard tuning changed from A=440 to A=442 on 1/1/94

E37762xxx Individual bars for M48

(Ex: Middle C = E37762CN4, 1/2 step up is E37762CS4)



E9450

E9450 Damper bar assembly

E9487 Male plastic knob


E3476 Low end damper arm

E3477 High end damper arm




E9487

M48S Pro Traveler Vibraphone




E3646




E3630

- E3646 Motor and control assy
- E36191 Motor w/connector
- E3634 Motor control unit
- E3617 ON/OFF switch
- E3632 Small potentiometer
- E3621 Control box mounting bracket
- E3630 Speed control knob
- E30601 Motor Panel w/Pins



E94361

- E94361 Plain resonator and pulsator assembly
- E9438 Plain pulsator shaft assembly



E3497

- E3497 Belt cover plate



E94371

- E94371 Sharp resonator and pulsator assembly
- E9439 Sharp pulsator shaft assembly
- E3154 LE bearing bracket
- E3156 Center bearing brkt
- E3155 HE bearing bracket
- E3157 Nyliners
- E9487 1/4-20 plastic male knob



E3631



E0412

- E0412 Motor mounting ring



E0408


- E3631 Motor Pulley

- E0408 Belt




E9487

E9487 fastens resonator sections as shown below.




E33281

- E33281 Resonator pulley



- E9457 #1 Rail assembly (closest to player)
- E9459 #2 Rail assembly
- E4491 Add on carrier bracket (for diag. braces)
- E9461 #3 Rail assembly
- E9463 #4 Rail assembly (farthest from player)
- E3017 Hinge assembly (same on all 4 rails)

M48S parts, cont



E94901


E94901 Crossbar assembly

- A** **E9494** Low end leg brace
- B** **E94862** Low end crossbar brace
- C** **E94565** High end crossbar brace
- D** **E9493** High end leg brace
- P1354** Plastic T handle knob
- E4491** Add-on carrier bracket
- E2590** Wing nut (braces to frame)




E0900T

E0900T Saddle post (10 pk)
40 per instrument




E0901T

E0901T Hook Post (10 pk)
40 per instrument



E0905

E0905 End post
4 per instrument
Used on rails 1 & 4




E0912

E0912 End Post
4 per instrument



P1534

P1534 T handle



E0117

E0117 Caster



E0300T


E0300T Post Insulator (10 pk)
88 per instrument

Parts of E9471 low end assembly

- E3456** Rail Bracket for #1
- E34411** Rail Bracket for #2
- E34401** Rail Bracket for #3
- E9472** Rail Bracket for #4
- E3216** LE damper bracket
- E3125** LE resonator plate, plain
- E3126** LE resonator plate, sharp
- E3127** LE resonator rubber (2)
- E3131** Fiber plate (2)
- E0302** Insulator (4)

Parts of E9474 HE assembly

- E3547** HE rail bracket for #1
- E9475** HE rail bracket for #4
- E0302** Insulator (2)



E94782 LE leg
E9471 LE assy

E94792 HE leg
E9474 HE assy

P1534 Plastic T-handle

P1534 connects leg assemblies to end pcs.




E1902V

E1902V Cord Spring (2 pk)
Order 2 packs for one instrument

E4441V Green bar cord (2 pk)

Used on rails 2 & 3


M48S parts, cont




E94962 Pedal and Pulrod assy
P1534 Female T handle (not shown)

(P1534 connects the pedal to crossbar)

- E9487** Male plastic knob
(E9487 secures lower pullrod to upper)
- E7323T** Pedal felt (10 pk)



E3474
E3474 Upper pullrod



E3476 Low end damper arm
E3216 Mounting clip for E3476
E3477 High end damper arm
E3217 Mounting clip for E3477



E9487



E2477

E2477 Wing nut



E3206

E3206 Felt Washer




E32031

E32031 Damper adj nut




E32111

E32111 Damper spring




E3213

E3213 Damper spring bracket




E3279

E3279 Damper felt 1/2" X 1 1/2" X 51"



E9450

E9450 Damper bar assembly
E9487 Male plastic knob
E3476 Low end damper arm
E3477 High end damper arm



E37761FUL

E37761FUL Full set of bars for M48S tuned to A=442

E37761FULW0 Full set of bars for M48S tuned to A=440

Standard tuning changed from A=440 to A=442 on 1/1/94

E37761xxx Individual bars for M48S

(Ex: Middle C = E37761CN4, 1/2 step up is E37761CS4)




E9487

M50 Pro Portable Xylophone



E38601




E38611

E38601 Low end leg assy
E38611 High end leg assy



E50370030

E50370030 Frame W/ Hardware
E39451 Handle
E9520 Velcro leg strap




E0140



E6160

E6160 leg insert for adj ht expandable stem casters



E4340

E4340 Resonator assy, plain

E0140 plain caster for adj ht inst

E0141 brake caster for adj ht inst

E0135 plain caster for fixed ht inst

E0136 brake caster for fixed ht inst



E4341

E4341 Resonator assy, sharp




E6161



E9784

E6161 5/16"-18 Plastic knob

E9784 5/16"-18 Thru knob



E3937

E3937 LE resonator rubber



E4114

E4114 HE resonator rubber

M50 parts, cont.




E0305T

E0305T Post insulator
104 on instrument



E0900T

E0900T Saddle Posts (10pk)
94 on instrument



E0905


E0905 Corner post
8 on instrument



E1902V

E1902V Bar Cord Spring (2pk)
Order 2 packs for one instrument

E4441V Bar cord
One pack per instrument



E4101FUL

E4101FUL Set of bars for M50 tuned to A=442
Includes bar cord and springs

NOTE: Xylophone bars have always been A=442

E4101xxx Individual bars for M50

(Ex: E4101FN4 is lowest bar, 1/2 step up is E4101FS4)

E4101TR Tune and re-finish M50 bars, per octave



E4074



E4069

E4074 HE leg brace

E4069 LE leg brace

E4491 Add on Carrrier Bracket

E2590 Wing Nut

E2460 1/4-20 lock nut


E2590 connects brace to leg assy

E2460 connects brace to Carrier Bracket

M51 Pro Portable Xylophone



E38601




E38611

E38601 Low end leg assy
E38611 High end leg assy



E50370030

E50370030 Frame W/ Hardware
E39451 Handle
E9520 Velcro leg strap




E0140



E6160

E6160 leg insert for adj ht expandable stem casters



E4340

E4340 Resonator assy, plain

E0140 plain caster for adj ht inst

E0141 brake caster for adj ht inst

E0135 plain caster for fixed ht inst

E0136 brake caster for fixed ht inst



E4341

E4341 Resonator assy, sharp




E6161



E9784

E6161 5/16\"-18 Plastic knob

E9784 5/16\"-18 Thru knob



E3937

E3937 LE resonator rubber



E4114

E4114 HE resonator rubber

M51 parts, cont.




E0305T

E0305T Post insulator
104 on instrument



E0900T

E0900T Saddle Posts (10pk)
94 on instrument



E0905


E0905 Corner post
8 on instrument



E1902V

E1902V Bar Cord Spring (2pk)
Order 2 packs for one instrument

E4441V Bar cord
One pack per instrument



E3850FUL

E3850FUL Set of bars for M51 tuned to A=442
Includes bar cord and springs

NOTE: Xylophone bars have always been A=442

E3850xxx Individual bars for M51

(Ex: E3850FN4 is lowest bar, 1/2 step up is E3850FS4)

E3850TR Tune and re-finish M51 bars, per octave.



E4074



E4069

E4074 HE leg brace

E4069 LE leg brace

E4491 Add on Carrrier Bracket



E2590 Wing Nut

E2460 1/4-20 lock nut

E2590 connects brace to leg assy

E2460 connects brace to Carrier Bracket

M55 Pro-Vibraphone



E3645S

E3645S Motor and control assy

E36191 Motor w/connector

E3634 Motor control unit

E3617 ON/OFF switch

E3617 solders onto pc board or solder on lead wires.

E3632 Small potentiometer

E3626 Control box mounting bracket

E3178 Old style Bodine motor


E3630 Speed control knob



E3631



E0407



E3630




E0412

E3631 Motor Pulley

E0412 Motor mounting ring

E0407 Vibe motor belt


5 3/4" dia. (18.06" long)



E3465

E3465 Resonator and pulsator assembly, plain

E3466 Resonator and pulsator assembly, sharp



E3466

E3463 Pulsator shaft assembly, plain

E3464 Pulsator shaft assembly, sharp

E3154 Low end bearing bracket w/o nyliner


E3156 Center bearing bracket w/o nyliner

E3155 High end bearing bracket w/o nyliner

E3157 Nyliner


E4065 Resonator rubber (4 per inst) low end only

E4061 Resonator plate (4 per inst) low end only



E3497


E3497 Belt Cover plate



E33281


E33281 Pulsator shaft pulley

M55 parts, cont.




E50380050

- E50380050** M55 Frame w/hardware & motor
- E50380040** M55 Frame w/hardware- no motor
(comes with damper bar installed)
- E3791** Node wire, plain
- E3792** Node wire, sharp



E38605




E38615

- E38605** LE adj ht leg assy
- E38615** HE adj ht leg assy

order leg extensions and casters separately

To convert to adj ht legs, order:

qty	Part #	description
1	E38615	HE leg assy
1	E38605	LE leg assy
4	E6160	Leg extension
2	E0140	Caster, plain
2	E0141	Caster, brake
4	E6161	Knob w/ stud
4	E9784	Thru hole knob
2	E9520	Velcro strap 16"



E3486

E3486 Lower crossbar with diagonal braces.

- A** **E34801** Low end leg brace
- B** **E94567** Low end crossbar brace
- C** **E94568** High end crossbar brace
- D** **E34811** High end leg brace
- E4491** Add on carrier bracket
- E2590** 1/4-20 wing nut


Tops of diagonal braces connect to E4491 bracket with E2590 wing nut

This crossbar will work on models made after 1980, and earlier models with some modifications.



E6160

E6160 Leg extension



E0140

E0140 Exp stem caster, plain (adj ht)

E0141 Exp stem caster, brake (adj ht)

E0135 Exp stem caster, plain (fixed ht)

E0136 Exp stem caster, brake (fixed ht)



E6161

E6161 5/16-18 Plastic knob




E9784

E9784 5/16-18 Thru-knob



E0900T

E0900T Saddle post (10 pk)
40 per instrument




E0901T

E0901T Hook Post (10 pk)
40 per instrument




E0300T

E0300T Post insulator (10 pk)
88 per instrument



E0905


E0905 End post
4 per instrument
Used on rails 1 & 4



E0912

E0912 End post
4 per instrument
Used on rails 2 & 3


M55 parts, cont



E3476


E3477

- E3476** Low end damper arm
- E3272** Mounting clip for E3476
- E3477** High end damper arm
- E3217** Mounting clip for E3477



E3200


- E3200** Damper bar assembly
- E3215** Eye hook 1/4 20 x 2"
- E2455** Hex nut 1/4 20
- E3202** Damper stud



E94965


E3474

- E94965** Pedal assy w/lower plrd (after 1/2/01)
- E94963** Pedal assy w/lower plrd (before 1/2/01)
- E9784** Thru knob to secure to crossbar (after 1/2/01)
- E3474** Upper pull rod




E3279

- E3279** Damper felt 1/2" X 1 1/2" X 51"




E32261

- E32261** Lower pullrod only
- E9487** Adjustment knob



E37761FUL

- E37761FUL** Full set of bars for M55 tuned to A=442
- E37761FULW0** Full set of bars for M55 tuned to A=440
- Standard tuning changed from A=440 to A=442 on 1/1/94
- E37761xxx** Individual bars for M55
- (Ex: Middle C = E37761CN4, 1/2 step up is E37761CS4)



E32111

- E32111** Damper Spring
- E3952** Damper spring bracket



E9487




E1902V

- E1902V** Cord Spring (2 pk)
- Order 2 packs for one instrument
- E4441V** Bar cord
- Order 1 pack for one instrument



E2477

- E2477** Wing nut for damper spring



E32031



- E32031** Damper adjustment nut



E3206

- E3206** Felt washer

M55G Pro-Vibraphone



E3645S

- E3645S Motor and control assy
- E36191 Motor w/connector
- E3634 Motor control unit
- E3617 ON/OFF switch

E3617 solders onto pc board or solder on lead wires.


- E3632 Small potentiometer
- E3626 Control box mounting bracket
- E3178 Old style Bodine motor
- E3630 Speed control knob



E0412



E0407




E3630




E3631

- E3631 Motor Pulley
- E0412 Motor mounting ring
- E0407 Vibe motor belt
5 3/4" dia. (18.06" long)




E3497

E3497 Belt Cover plate




E33281

E33281 Pulsator shaft pulley



E34651

- E34651 Resonator and pulsator assembly, plain
- E34661 Resonator and pulsator assembly, sharp




E34661

- E34631 Pulsator shaft assembly, plain
- E34641 Pulsator shaft assembly, sharp
- E31541 Low end bearing bracket w/o nyliner
- E31561 Center bearing bracket w/o nyliner
- E31551 High end bearing bracket w/o nyliner
- E3157 Nyliner
- E4065 Resonator rubber (4 per inst) low end only
- E4061 Resonator plate (4 per inst) low end only


M55G parts, cont.

- E39171** M55G frame number not assigned
Trim, LE HS Bottom Pdr Ct, 4 ea
E39181 Trim, HE HS Top Pdr Ct, 4 ea

- M55G Frame w/hardware & motor
M55G Frame w/hardware- no moto
(comes with damper bar installed)
E3791 Node wire, plain
E3792 Node wire, sharp



E38605 LE adj ht leg assy
E38615 HE adj ht leg assy



E38615

order leg extensions and casters separately


To convert to adj ht legs, order:

qty	Part #	description
1	E38615	HE leg assy
1	E38605	LE leg assy
4	E6160	Leg extension
2	E0140	Caster, plain
2	E0141	Caster, brake
4	E6161	Knob w/ stud
4	E9784	Thru hole knob
2	E9520	Velcro strap 16"



E0300T

E0300T Post insulator (10 pk)
88 per instrument



E3486

E3486 Lower crossbar with diagonal braces.


- A** **E34801** Low end leg brace
B **E94567** Low end crossbar brace
C **E94568** High end crossbar brace
D **E34811** High end leg brace
E4491 Add on carrier bracket
E2590 1/4-20 wing nut

Tops of diagonal braces connect to E4491 bracket with E2590 wing nut

This crossbar will work on models made after 1980, and earlier models with some modifications.



E6160



E0140



E6161



E9784

E6161 5/16-18 Plastic knob
E9784 5/16-18 Thru-knob

E6160 Leg extension

E0140 Exp stem caster, plain (adj ht)

E0141 Exp stem caster, brake (adj ht)

E0135 Exp stem caster, plain (fixed ht)

E0136 Exp stem caster, brake (fixed ht)



E0900T

E0900T Saddle post (10 pk)
40 per instrument



E0901T

E0901T Hook Post (10 pk)
40 per instrument



E0905

E0905 End post
4 per instrument
Used on rails 1 & 4



E0912

E0912 End post
4 per instrument
Used on rails 2 & 3

M55G parts, cont




E3476




E3477

- E3476** Low end damper arm
- E3272** Mounting clip for E3476
- E3477** High end damper arm
- E3217** Mounting clip for E3477




E94966



E34741

- E94966** Pedal assy w/lower plrd (after 1/2/01)
- E94964** Pedal assy w/lower plrd (8/4/97-1/02/01)
- E39071** Pedal assy w/lower plrd (before 8/4/97)
- E9784** Thru knob to secure to crossbar (after 1/2/01)
- E34741** Upper pull rod



E37762FUL

- E37762FUL** Full set of bars for M55G tuned to A=442
- E37762FULW0** Full set of bars for M55G tuned to A=440
- Standard tuning changed from A=440 to A=442 on 1/1/94
- E37762xxx** Individual bars for M55
- (Ex: Middle C = E37762CN4, 1/2 step up is E37762CS4)




E1902V

- E1902V** Cord Spring (2 pk)
- Order 2 packs for one instrument
- E4441V** Bar cord
- Order 1 pack for one instrument




E2477

E2477 Wing nut for damper spring




E3200

- E3200** Damper bar assembly
- E3215** Eye hook 1/4 20 x 2"
- E2455** Hex nut 1/4 20 (2 req to hold eye hook)
- E3202** Damper stud




E3279

E3279 Damper felt 1/2" X 1 1/2" X 51"



E32262

- E32262** Lower pullrod only
- E9487** Adjustment knob




E32111

- E32111** Damper Spring
- E3952** Damper spring bracket



E9487



E32031



- E32031** Damper adjustment nut



E3206

- E3206** Felt washer

M75 Century Vibraphone



E3646

- E3646** Motor and control assy
- E36191** Motor w/connector
- E3634** Motor control unit
- E3617** ON/OFF switch
- E3632** Small potentiometer
- E3621** Control box mounting bracket
- E3630** Speed control knob
- E3631** Motor pulley
- E30601** Motor Panel w/Pins




E0412



E0408

- E0412** Motor mounting Ring
- E0408** Vibe motor Belt
6" dia. (18.385 long)




E3630




E4342

- E4342** Resonator and pulsator assembly, plain
- E4343** Resonator and pulsator assembly, sharp




E3497

- E3497** Belt Cover plate
Will fit older models with some work.



E4343

- E4354** Pulsator shaft assembly, plain
- E4355** Pulsator shaft assembly, sharp
- E31541** Low end bearing bracket w/o nyliner
- E31561** Center bearing bracket w/o nyliner
- E31551** High end bearing bracket w/o nyliner
- E3157** Nyliner




E33281



E3631

- E33281** Pulsator shaft pulley
Older models used this on the motor also



E0128




E0129

- E0128**
- E0129**

- 3" Caster w/brake
- 3" Caster, plain

M75 parts, cont.



E4181


E4181 Low end assembly

- E3125** Low end resonator plate, plain
- E3126** Low end resonator plate, sharp
- E3127** Low end resonator rubber (2 per)
- E3546** #1 LE rail bracket
- E34411** #2 LE rail bracket
- E34401** #3 LE rail bracket
- E3552** #4 LE rail bracket, top
- E3553** #4 LE rail bracket, bottom


E4180 High end assembly

- E3547** #1 HE rail bracket
- E3555** #4 HE rail bracket, top
- E3556** #4 HE rail bracket, bottom

- E3499** Crossbar and Lyre assembly
- E3475** Lyre assembly only
- E97892** Diagonal brace (2 required)
- P1534** Female "T" handle for braces




- E3219** Pedal and lower pullrod
- E32262** Lower pullrod only
- E9487** Knob for pullrod
- E7323T** Pedal felt (10 pk)




E34741

E34741 Upper pullrod




E3258

E3258 Rail #1 (Closest to player)




E3259

E3259 Rail #2




E3260

E3260 Rail #3



E3261

E3261 Rail #4 (Closest to Audience)




E3499




E0900T

E0900T Saddle post (10pk)
40 per instrument



E0901T

E0901T Hook Post (10 pk)
40 per instrument



E0905

E0905 End Post
4 per inst, 1&4 rails



E0912


E0912 End Post
4 per inst, 2&3 rails



E0300T


E0300T Post insulator (10 pk)
88 per instrument

M75 parts, cont.



E3200


- E3200** Damper bar assembly
- E3215** Eye hook 1/4 20 x 2"
- E2455** Hex nut 1/4 20 (2 req to hold eye hook)
- E3202** Damper stud



E3476

E3477

- E3476** Low end damper arm
- E3216** Mounting clip for E3476
- E3477** High end damper arm
- E3217** Mounting clip for E3477



E3279

E3279 Damper felt, 1/2" x 1 1/2" x 51"




E32111




E3213

- E32111** Damper spring
- E3213** Damper Spring bracket



E37762FUL

- E37762FUL** Full set of bars for M75, tuned to A=442
- E37762FULW0** Full set of bars for M75, tuned to A=440
- Standard tuning changed from A=440 to A=442 on 1/1/94
- E37762xxx** Individual bars.
- (Ex: Middle C = E37762CN4, 1/2 step up is E37762CS4)




E32031



E3206

- E32031** Damper adjustment nut
- E3206** Felt Washer



P1534



E2477

- E2477** Wing nut
- Used to lock damper spring

- P1534** Female "T" handle for braces





E1902V

- E1902V** Pack of 2 springs
- Order 2 packs for one instrument

- E4441V** Green bar cord
- One pack does one instrument

M75LH Century Vibe



E3646

- E3646** Motor and control assy
- E36191** Motor w/connector
- E3634** Motor control unit
- E3617** ON/OFF switch
- E3632** Small potentiometer
- E3621** Control box mounting bracket
- E3631** Motor pulley
- E3630** Speed control knob
- E30601** Motor Panel w/Pins



E3631



E3630




E0408




E0412

- E0412** Motor mounting Ring
- E0408** Vibe motor Belt
6" dia. (18.385 long)




E4342H

- E4342H** Resonator and pulsator assembly, plain
- E4343H** Resonator and pulsator assembly, sharp




E3497

- E3497** Belt Cover plate
Will fit older models with some work.



E4343H

- E4354** Pulsator shaft assembly, plain
- E4355** Pulsator shaft assembly, sharp
- E31541** Low end bearing bracket w/o nyliner
- E31561** Center bearing bracket w/o nyliner
- E31551** High end bearing bracket w/o nyliner
- E3157** Nyliner



E33281

- E33281** Pulsator shaft pulley
Older models used this on the motor also




E0128



E0129

- E0128** 3" Caster w/brake
- E0129** 3" Caster, plain

M75LH parts, cont.



E41901H

E41901H Low end assembly

- E3125** Low end resonator plate, plain
- E3126** Low end resonator plate, sharp
- E3127** Low end resonator rubber (2 per)
- E3546** #1 LE rail bracket
- E34411** #2 LE rail bracket
- E34401** #3 LE rail bracket
- E3552** #4 LE rail bracket, top
- E3553** #4 LE rail bracket, bottom

E41911H High end assembly

- E3547** #1 HE rail bracket
- E3555** #4 HE rail bracket, top
- E3556** #4 HE rail bracket, bottom

- E3499H** Crossbar and Lyre assembly
- E97892H** Diagonal brace (2 required)
- P1534** Female "T" handle for braces




E3219H

- E3219H** Pedal and lower pullrod
- E32262** Lower pullrod only



E9487

- E9487** Knob for pullrod
- E7323T** Pedal felt (10 pk)




E3499H




E0900T

- E0900T** Saddle post (10pk)
- 40 per instrument



E0901T

- E0901T** Hook Post (10 pk)
- 40 per instrument



E0905

- E0905** End Post
- 4 per inst, 1&4 rails




E0912

- E0912** End Post
- 4 per inst, 2&3 rails




E0300T

- E0300T** Post insulator (10 pk)
- 88 per instrument




E3258H

E3258H Rail #1 (Closest to player)




E3259H

E3259H Rail #2




E3260H

E3260H Rail #3



E3261H


E3261H Rail #4 (Closest to Audience)



E34741


E34741 Upper pullrod

M75LH parts, cont.




E3200

- E3200** Damper bar assembly
- E3215** Eye hook 1/4 20 x 2"
- E2455** Hex nut 1/4 20 (2 req to hold eye hook)
- E3202** Damper stud



E3279

E3279 Damper felt, 1/2" x 1 1/2" x 51"



E37762FUL


- E37762FUL** Full set of bars for M75LH, tuned to A=442
 - E37762FULW0** Full set of bars for M75LH, tuned to A=440
A=442 is standard tuning.
 - E37762xxx** Individual bars.
- (Ex: Middle C = E37762CN4, 1/2 step up is E37762CS4)



E1902V

E1902V Pack of 2 springs
Order 2 packs for one instrument


E4441V Green bar cord
One pack does one instrument



E3476

E3477

- E3476** Low end damper arm
- E3216** Mounting clip for E3476
- E3477** High end damper arm
- E3217** Mounting clip for E3477




E32111



E3213

- E32111** Damper spring
- E3213** Damper Spring bracket




E32031



E3206

- E32031** Damper adjustment nut
- E3206** Felt Washer



P1534





E2477

E2477 Wing nut
Used to lock damper spring


P1534 Female "T" handle for braces

M250 Concert Grand Marimba



E3048

E3049



E4007

E4007 M250 Resonator Assy, Sharp



E4006

E4006 M250 Resonator Assy, Plain



E4122

E4122 Crossbar assembly

- includes:
- E9784** 5/16-18 thru knob, plastic (3)
 - E6811** 5/16-18 male knob, plastic (3)
 - E30153** Crossbar sleeve (2)

not incl >> **E16625** Screws for E30153 #10 x 1.75"

In Nov of 01, the crossbar changed to this type.
Was held in place with spring loaded pins, now
uses male knobs and thru knobs at ends and center.



E9784



E6811

E3048

LE Assembly

- E3546** LE Rail Brkt (#1 rail)
- E34411** Right Rail Brkt w/pin (#2 rail)
- E34401** Left Rail Brkt w/pin (#3 rail)
- E3552** LE Rail Brkt, top (#4 rail)
- E3553** LE Rail Brkt, bottom (#4 rail)
- E0302** Insulator (one for each rail)
- E9324** Brace plate (w/ 1/4-20 stud)
- E4140** LE resonator plate (2 req)
- E4141** LE resonator rubber (2 req)
- E30153** Crossbar sleeve (not included)
(Casters not included)

E3049

HE Assembly

- E3547** HE Rail bracket (#1 rail)
- E34401** Left Rail Brkt w/pin (#2 rail)
- E34411** Right Rail Brkt w/pin (#3 rail)
- E3555** HE Rail Brkt, top (#4 rail)
- E3556** HE Rail Brkt, bottom (#4 rail)
- E9324** Brace plate (w/ 1/4-20 stud)
- E3012** HE Resonator plate
- E4142** HE Resonator rubber
- E4143** HE Resonator spacer
- E30153** Crossbar sleeve (not included)
(Casters not included)



E0128




E0129

E0128 3" Caster w/brake

E0129 3" Caster plain


E1641 #12x1" caster screws (not incl)

M250 parts, cont.




E4016

E4016 #1 Rail assembly (closest to player)
E6808 Node wire




E4017

E4017 #2 Rail assembly



E4018

E4018 #3 Rail assembly



E4019

E4019 #4 Rail assembly (closest to audience)
E6804 Node wire

NOTE: Rail assemblies do not come w/ insulators



E0300T

E0300T Insulator (10 pk)
124 per instrument



E1902V

E1902V Cord spring (2pk)
4 per instrument



E0900T

E0900T Saddle Post (10pk)
116 per instrument




E0905

E0905 End post (8 per inst)

E4441V Green bar cord (2pk)

E93581



E93581 Diagonal brace (2)



E2590

E2590 Wing nut for diag brace (4)

E4135FUL Full set of bars for M250, tuned A=442


E4135FULW0 Full set of bars for M250, tuned A=440

Standard tuning changed from A=440 to A=442 on 1/1/94

E4135xxx Individual bars for M250


(Ex: Middle C is E4135CN4, 1/2 step up is E4135CS4)

E4135TR Tune and re-finish M250 bars, per octave




E4135FUL

M300 Classic Grand Marimba



E4622




E4623




E4634

E4634 Resonator assembly, sharp



E4633

E4633 Resonator assembly, plain



E4635

E4635 Crossbar assembly (includes E30151)
E30151 Crossbar sleeve, reamed & painted



E0128

E0128 3" Caster, Brake
E0129 3" Caster, Plain



E0129



E2590

E2590 Wing nut
for diagonal brace (4)

- E4622** Low end assembly
- E4141 LE Resonator rubber (2 req)
 - E3061 LE Fibre plate (4 req)
 - E4140 LE Resonator plate (2 req)
 - E3546 LE Rail Brkt (#1 rail)
 - E34411 Right Rail Brkt w/pin (#2 rail)
 - E34401 Left Rail Brkt w/pin (#3 rail)
 - E3552 LE Rail Brkt, top (#4 rail)
 - E3553 LE Rail Brkt, bottom (#4 rail)
 - E0302 Insulator (one for each rail)
 - E46392 Horseshoe trim (4 req)
 - E46402 Upright trim (2 req)

(casters, brace plate and crossbar sleeve not included)

- E4623** High end assembly
- E9317 HE Resonator rubber
 - E9321 HE Resonator plate
 - E3547 HE Rail bracket (#1 rail)
 - E34401 Left Rail Brkt w/pin (#2 rail)
 - E34411 Right Rail Brkt w/pin (#3 rail)
 - E3555 HE Rail Brkt, top (#4 rail)
 - E3556 HE Rail Brkt, bottom (#4 rail)
 - E0302 Insulator (one for each rail)
 - E46392 Horseshoe trim (4 req)
 - E46402 Upright trim (2 req)

(casters, brace plate and crossbar sleeve not included)


- E9324 Brace plate w/ 1/4-20 stud

E93581




E93581 Diagonal brace (2)

M300 parts, cont.




E4625

E4625 #1 rail assembly (closest to player)
E9340 Nodal wire




E4627

E4627 #2 rail assembly



E4629

E4629 #3 rail assembly



E4631

E4631 #4 rail assembly (closest to audience)
E9341 Nodal wire

NOTE: Rail assemblies do not come w/ insulators.



E0301

E0301 Post insulator (116 per instrument)




E0300T

E0300T Post insulator, (10pk)

Instrument uses 8, so buy 1 pack.

Before 10/20/05, M300 used 124 E0300, or 10 pks of E0300T



E0905

E0905 End post
 (8 per instrument)



E0900T

E0900T Saddle post (10 pk)
 (116 per instrument)



E1902V

E1902V Cord spring (2pk)
 4 per instrument

E4441V Green bar cord (2pk)


E4624FUL Full set of bars for M300, tuned A=442

E4624FULW0 Full set of bars for M300, tuned A=440

Standard tuning changed from A=440 to A=442 on 1/1/94



E4624XXX Individual bars for M300

(Ex: Middle C is E4624CN4, 1/2 step up is E4135CS4)



E4624FUL

M635B Classic Chimes



E50260010

M635BF M665B Less Tubes




E7340

E7340 Upright tube




E7342

E7342 Top Support



E73451

E73451 Leg casting L/R



P1447


P1447 3" Locking caster



E7289


E7289 Chime hanger bar, natural

E7290 Chime hanger bar, sharp



E7346

E7346 Lower crossbar



E7216

E6216 Diagonal brace

E2357 1/4-20x3/4 cap scrw for bottom

E2358 1/4-20x1/2 cap screw for top

E2580T Set screw kit (12pcs) for frame.

contains: (8) E2580 5/16-18 x 3/8

(4) E2579 5/16-18 x 5/8

(not incl)

E0372 5/32" Allen wrench

(not incl)

(not incl)

M635B parts, cont.




E73481
E37481 Pedal/pullrod assy




E32262
E32262 Lower pullrod
(Includes E9487 knob and E3235 pullrod stud)



E9487
E9487 1/4-20 plastic knob



E34741
E34741 Upper pullrod assy



E7353 Damper box assembly




E73211
E73211 Damper box grille

- E7351** Side casting
- E73211** Damper box grille
- E7329** Top damper board
- E73301** Middle damper board
 - E7312** Chime roller bracket
 - E1433** #6x1 tapping screw
- E7331** bottom damper board
 - E7313** Chime lever assy.
- E7323T** damper felt, 10pk
- E2359** 1/4-20x1 cap screw (16 per)




E7313
E7313 Chime lever assembly



E7351 Side casting (1)





E4727T
E4727T Chime cable kit (10pk)



E1462FUL

- E1462FUL** Set of tubes for M635B, A=442
- E1462FULW0** Set of tubes for M635B, A=440
- E1462xxx** Individual bars for M635B
ex, E1462CN5 = lowest C natural.
ex, E1462CS5 = C sharp 1/2 step up.

M635C Classic Chimes



E50760010

M635CF M635C Less tubes




E6340

E6340 Upright tube




E6342

E6342 Top Support



E6345

E6345 Leg casting L/R



P1447


P1447 3" Locking caster



E7289


E7289 Chime hanger bar, natural

E7290 Chime hanger bar, sharp



E6346

E6346 Lower crossbar



E6216

E6216 Diagonal brace

E2580T Set screw kit (12pcs) for frame.

contains: (8) E2580 5/16-18 x 3/8

(4) E2579 5/16-18 x 5/8

(not incl)

E0372 5/32" Allen wrench

(not incl)

(not incl)

E2357 1/4-20x3/4 cap scrw for bottom

E2358 1/4-20x1/2 cap screw for top

M635C parts, cont.



E6348

E6348 Pedal/pullrod assy




E32261

E32261 Lower pullrod
(Includes E9487 knob and E3235 pullrod stud)




E9487

E9487 1/4-20 plastic knob



E3474

E3474 Upper pullrod assy



E6353

E6353 Damper box assembly



E73211


E73211 Damper box grille

- E7351 Side casting
- E73211 Damper box grille
- E7329 Top damper board
- E73301 Middle damper board
 - E7312 Chime roller bracket
 - E1433 #6x1 tapping screw
- E7331 bottom damper board
 - E7313 Chime lever assy.
- E7323T damper felt, 10pk
- E2359 1/4-20x1 cap screw (16 per)



E7313

E7313 Chime lever assembly




E6351

E6351 Side casting (1)



E4727T

E4727T Chime cable kit (10pk)



E1463FUL

E1463FUL Set of tubes for M635C, A=442



E1463FULW0 Set of tubes for M635C, A=440

E1643xxx Individual bars for M635C

ex, E1463CN5 = lowest C natural.

ex, E1463CS5 = C sharp 1/2 step up.


M645 Classic Orchestra Bells



E50780020


E50780020 Frame w/felt
M645F M645 less bars.

(Includes pin & insulators, but not mounting screws & gromets.)



E0224

E0224 Wood case only.



E3590FUL


E3590FUL Set of bars for M645, A=442

E3590FULW0 Set of bars for M645, A=440

E3590xxx Individual bars for M645

ex: E3590GN5 = lowest bar in set.

ex: E3590GS5 = G# 1/2 step up.



E3039T

E3039T Screw & Bushing assy, 10pk
 (30 per instrument, buy 3 packs).



E0590T

E0590T Rubber bushing, 10pk
 (30 per instrument, buy 3 packs).




E1808T

E1808T Mounting screw only, 10pk
 (30 per instrument, buy 3 packs).




E3786T

E3786T Pin & Insulator assy, 10pk
 (36 per instrument, buy 4 packs).



E0312T

E0312T Insulator, 10pk
 (36 per instrument, buy 4 packs).




E83762

E83762 Felt strips, set of 4.

E4447V White bar cord, cut to length for M645/M646.


M646 Classic Orchestra Bells w/Damper



E3560


E3560 Wood frame, painted and drilled.

M646F M646 less bars. (Incl mounting screws)
(Includes pins & insulators and screws & gromets).



E0222

E0222 Wood Case only



E3590FUL

E3590FUL Set of bars for M646, A=442

E3590FULW0 Set of bars for M646, A=440

E3590xxx Individual bars for M646

ex: E3590GN5 = lowest bar in set.

ex: E3590GS5 = G# 1/2 step up.



E3039T

E3039T Screw & Bushing assy, 10pk
(30 per instrument, buy 3 packs).

E0590T

E0590T Rubber bushing, 10pk
(30 per instrument, buy 3 packs).



E1808T

E1808T Mounting screw only, 10pk
(30 per instrument, buy 3 packs).




E3786T

E3786T Pin & Insulator assy, 10pk
(36 per instrument, buy 4 packs).

E0312T

E0312T Insulator, 10pk
(36 per instrument, buy 4 packs).





E83762

E83762 Felt strips, set of 4.

E3578 Felt strips for damper rails (ea.)


E4447V White bar cord, cut to length for M645/M646.

M656 Concert Band Bells




E50850020

E50850020 Frame only
(Includes felt and screw & bushing assemblies.)



E3039T

E3039T Screw & Bushing assy, 10pk
(60 per instrument, buy 6 packs).



E0590T

E0590T Rubber bushing, 10pk
(60 per instrument, buy 6 packs).

E0224




E0224 Wood case only.




E1808T

E1808T Mounting screw only, 10pk
(60 per instrument, buy 6 packs).



E83862

E83762 Felt strips, set of 4.



E4251FUL

E4251FUL Set of bars for M656, A=442



E4251FULW0 Set of bars for M656, A=440

E4251xxx Individual bars for M656

ex: E4251GN5 = lowest bar in set.

ex: E4251GS5 = G# 1/2 step up.

M661C Symphonic Chimes



E50280010

M661CF M661C Less tubes




E6341

E6341 Upright tube




E6342

E6342 Top Support



E6345

E6345 Leg casting L/R



P1447


P1447 3" Locking caster



E7289


E7289 Chime hanger bar, natural

E7290 Chime hanger bar, sharp



E6346

E6346 Lower crossbar



E6216

E6216 Diagonal brace

E2580T Set screw kit (12pcs) for frame.

contains: (8) E2580 5/16-18 x 3/8

(4) E2579 5/16-18 x 5/8

(not incl) **E0372** 5/32" Allen wrench

(not incl)

(not incl)

E2357 1/4-20x3/4 cap scrw for bottom

E2358 1/4-20x1/2 cap screw for top

M661C parts, cont.



E6348

E6348 Pedal/pullrod assy




E32261

E32261 Lower pullrod
(Includes E9487 knob and E3235 pullrod stud)




E9487

E9487 1/4-20 plastic knob



E3474

E3474 Upper pullrod assy



E6354

E6354 Damper box assembly



E73211

E73211 Damper box grille

E7351 Side casting

E73211 Damper box grille

E73031 Top damper board

E73041 Middle damper board

E7312 Chime roller bracket

E1433 #6x1 tapping screw

E73051 bottom damper board

E7313 Chime lever assy.


E7324T damper felt, 10pk

E2359 1/4-20x1 cap screw (16 per)



E7313

E7313 Chime lever assembly




E6351

E6351 Side casting (1)



E4727T

E4727T Chime cable kit (10pk)



E7296FUL

E7296FUL Set of tubes for M661C, A=442



E7296FULW0 Set of tubes for M661C, A=440

E7296xxx Individual bars for M661C

ex, E7296CN5 = lowest C natural.

ex, E7296CS5 = C sharp 1/2 step up.

M665B Symphonic Chimes



E50270010

M665BF M665B Less tubes




E7341

E7341 Upright tube




E7342

E7342 Top Support



E73451

E73451 Leg casting L/R



P1447


P1447 3" Locking caster



E7289


E7289 Chime hanger bar, natural

E7290 Chime hanger bar, sharp



E7346

E7346 Lower crossbar



E7216

E6216 Diagonal brace

E2580T Set screw kit (12pcs) for frame.

contains: (8) E2580 5/16-18 x 3/8

(4) E2579 5/16-18 x 5/8

(not incl)

E0372 5/32" Allen wrench

(not incl)

(not incl)

E2357 1/4-20x3/4 cap scrw for bottom

E2358 1/4-20x1/2 cap screw for top

M655B parts, cont.




E73481 Pedal/pullrod assy




E32262 Lower pullrod
(Includes E9487 knob and E3235 pullrod stud)



E9487
E9487 1/4-20 plastic knob



E34741
E34741 Upper pullrod assy



E7354 Damper box assembly




E73211 Damper box grille

- E7351** Side casting
- E73211** Damper box grille
- E73031** Top damper board
- E73041** Middle damper board
 - E7312** Chime roller bracket
 - E1433** #6x1 tapping screw
- E73051** bottom damper board
 - E7313** Chime lever assy.
- E7324T** damper felt, 10pk
- E2359** 1/4-20x1 cap screw (16 per)




E7313 Chime lever assembly



E7351 Side casting (1)



E4727T Chime cable kit (10pk)



E7295FUL

- E7295FUL** Set of tubes for M665B, A=442
- E7295FULW0** Set of tubes for M665B, A=440
- E7295xxx** Individual bars for M665B
ex, E7295CN5 = lowest C natural.
ex, E7295CS5 = C sharp 1/2 step up.